



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	LR Corner Clip Angle	1 3/4" X 1 3/4" X 1/8" Angle
2	2	Stair Corner Clip Angle	1 3/4" X 3 3/4" X 1/8" Angle
3	6	5/16" x 4 1/2" Long Hex Hd Screw	Used for Stair to Landing/Rail Stops
4	2	5/16" "Type A" Washer	Used for Stair Stringer Spacer
5	10	5/16" Hex Nut (with Nylon Insert)	Used for all Hex Head Bolts
6	4	5/16" x 2 1/2" Long Hex Hd Cap Screw	Landing Legs to Landing Attachment
7	12	#14 x 3/4" Hex Hd Tek Screw	Used to Connect Clips to Rails
8	4	#10-3/4" PAN HD TEK SCREWS	Used to Connect Riser Plate to Landing
9	4	1/4" x 2" Lag Bolt	Used to Connect Rail to Building